



BRA-TYPE 17 SELF DRILLING ASSEMBLIES

For fastening the crests of corrugated and square rib roof sheeting in cyclonic regions.

One step fastening of corrugated and square rib sheeting eg. SuperDek®, CorruDek® and TileDek®

Type 17 self drilling screw for fastening to timber battens, and thin metal battens.

For profile heights, 16mm to 145mm

Available in lengths 50mm to 175mm

B8 protection to AS 3566 Class 4.

25mm diameter marine grade aluminium/ EPDM universal BRA cyclone washer (Specifically designed cyclone washer).

Available in all Colorfast colours

Tested & Certified to AS/NZS 1170.2 & BCA 2008 specification B 1.2 for the design of buildings in cyclonic areas.

Accepted for inclusion in the NT Deemed to Comply Manual

Fully covered by the Bremick Performance Warranty.

SuperDek®, CorruDek® and TileDek® are registered trademarks of Roofing & Profiles (Fiji) Ltd.

**Drills
Faster
Lasts
Longer**

A revolution in corrosion protection and drilling performance

Extreme
Corrosion
Protection
Superior
Drilling
Performance



ROOFING & PROFILES (FIJI) PTE LTD
Build With Confidence

ROOFING AND SHEETMETAL MANUFACTURERS

Factory: Phone: (679) 667 3764 Email: info@roofingandprofiles.com.fj www.roofingandprofiles.com.fj




BREMICK ROOFING ASSEMBLIES BRA CYCLONE FASTENERS

BRA-TYPE 17 SELF DRILLING ASSEMBLIES

For fastening the crests of corrugated and square rib roof sheeting in cyclonic regions.

PRODUCT DESCRIPTION

BRA TYPE 17 CYCLONE ASSEMBLY
FOR TIMBER & THIN METAL BATTENS



Thread	Size	Product Features	Pack Quantity	Product Code	Hexagonal Driver
Full	14g -10x50	B8,W	250	STHC81405D	3/8
Full	14g -10x65	B8,W	250	STHC81406D	3/8
Part	14g -10x75	B8,W,SP	250	STHC81407B	3/8
Part	14g -10x90	B8,W,SP	250	STHC81409B	3/8
Part	14g -10x100	B8,W,SP	250	STHC81410B	3/8
Part	14g -10x115	B8,W,SP	250	STHC81411B	3/8
Part	14g -10x125	B8,W,SP	250	STHC81412B	3/8
Part	14g -10x150	B8,W,SP	250	STHC81415B	3/8
Part	14g -10x175	B8,W,SP	250	STHC81417B	3/8

APPLICATIONS

One step fastening the crests of roof sheeting (16mm to 145mm rib heights) to timber and thin metal battens.

- SuperDek®
- CorruDek®
- TileDek®


INSTALLATION RECOMMENDATIONS

For best results use a power screw driver with variable speed., 1000 to 1500 RPM.
When fastening to timber (JD3 min.) ensure a minimum embedment of 29mm
The use of battery screw drivers will significantly decrease drilling speed.
Metal Battens 0.75mm BMT G550 min
Only use Bremick Drive Bits.
In cyclonic regions consult design professionals for fastener spacing


Vortex and Armourcoat are registered trade marks of Bremick Pty Ltd. Copyright ©2010

SETTING INSTRUCTIONS


1: Position
Fit screw head into drive socket and locate screw point at centre of sheet rib.
(BRA Cyclone washer can accommodate up to 11 degrees of axial misalignment)



2: Drill
With a power screw driver commence drilling at " slow speed " to pierce sheeting.



3: Set
Maintaining a firm down pressure increase the drive speed to penetrate the base material. Continue driving until the BRA Washer seats firmly.



BREMICK ROOFING ASSEMBLIES BRA CYCLONE FASTENERS

Exclusive Distributor in Fiji



ROOFING & PROFILES (FIJI) PTE LTD

Build With Confidence

ROOFING AND SHEETMETAL MANUFACTURERS

Factory: Phone: (679) 667 3764

Email: info@roofingandprofiles.com.fj

www.roofingandprofiles.com.fj